



Instrukcja montażu
Installation Guide
Montážní návod
Installationsanleitung
Instructions d'installation
Instruções de montagem


Instrucciones de instalación
Istruzioni per l'installazione
Upute za sastavljanje
Instrucțiuni de montaj
Návod na montáž




Toyota Avensis II Estate (2003-2009)

AV2K II BEZ KL

SOLARRIDE Dodávka rámečkových stínidel pro Toyota Avensis II (2003-2009) BEZ KL, 2x



5 904035 797209 >



6 x



