



Instrukcja montażu
Installation Guide
Montážní návod
Installationsanleitung
Instructions d'installation
Instruções de montagem

Instrucciones de instalación
Istruzioni per l'installazione
Upute za sastavljanje
Instrucțiuni de montaj
Návod na montáž




Fiat Freemont (2011-2015)

FREEMONT KPL

SOLARRIDE Zastlonki, osłony przeciwsłoneczne do FIAT FREEMONT 2011-2016 KPL 3kg



5 904035 792334 >



8 x





