



Instrukcja montażu
Installation Guide
Montážní návod
Installationsanleitung
Instructions d'installation
Instruções de montagem


Instrucciones de instalación
Istruzioni per l'installazione
Upute za sastavljanje
Instrucțiuni de montaj
Návod na montáž




Skoda Fabia II Estate Kombi (2007-2015)

FAB2K BEZ KL

SOLARRIDE Zakaznik / order / zamówienie: SolarRide Skoda Fabia II Kombi (2007-2015) BEZ KL



5 904035 798299 >



6 x



2 x



