



Instrukcja montażu  
Installation Guide  
Montážní návod  
Installationsanleitung  
Instructions d'installation  
Instruções de montagem


Instrucciones de instalación  
Istruzioni per l'installazione  
Upute za sastavljanje  
Instruțiuni de montaj  
Návod na montáž



Renault Megane III Estate (2008-2016)

**MEG3K DR**

SOLARRIDE Centerki, nišiny personalizowane do RENAULT MEGANE 3 i GRANDESIR 2008-2015 DR 1kg



**4 x**





Instrukcja montażu  
Installation Guide  
Montážní návod  
Installationsanleitung  
Instructions d'installation  
Instruções de montagem

Instrucciones de instalación  
Istruzioni per l'installazione  
Upute za sastavljanje  
Instrucțiuni de montaj  
Návod na montáž

