



Instrukcja montażu
Installation Guide
Montážní návod
Installationsanleitung
Instructions d'installation
Instruções de montagem


Instrucciones de instalación
Istruzioni per l'installazione
Upute za sastavljanje
Instrucțiuni de montaj
Návod na montáž




Mercedes-Benz GLA I (X156) (2013-2019)

GLA I KPL

SOLARRIDE Zubehör / rękawiczki / colarek przeciwsłoneczny SolarRide do Mercedes-Benz GLA I (X156) (2013-2019) KPL 2kg



5 904035 791160 >



4 x



4 x



