



Instrukcja montażu
Installation Guide
Montážní návod
Installationsanleitung
Instructions d'installation
Instruções de montagem

Instrucciones de instalación
Istruzioni per l'installazione
Upute za sastavljanje
Instrucțiuni de montaj
Návod na montáž




Opel Adam (2012-2019)

ADAM KPL

SOLARRIDE Zaslonki do OPEL ADAM 2012-2019 KOMPLET 2kg



5 904035 796134 >



4 x





