



Instrukcja montażu
Installation Guide
Montážní návod
Installationsanleitung
Instructions d'installation
Instruções de montagem


Instrucciones de instalación
Istruzioni per l'installazione
Upute za sastavljanje
Instrucțiuni de montaj
Návod na montáž




Peugeot 3008 I (2009-2016)

3008 I KPL

SOLARRIDE zaslonki, oslony przeciwsłoneczne do PEUGEOT 3008 (2009-2016) KPL 3kg



5 904035 792273 >



4 x



4 x



